


008 - Electrical/500 - Power Distribution Center, Fuse Block, Junction Block, Relays and Fuses

DESCRIPTION



Item	Description	Part Number	Qty	Supersedece	Tech Tip	Engine	Trans	Line	Body
1	POWER DISTRIBUTION CENTER	04692167AB	1	Yes		EX0			
	POWER DISTRIBUTION CENTER	04692164AB	1	Yes					
	POWER DISTRIBUTION CENTER	04692164AC	1	Yes					
2	RELAY, Mini								
		04671168	1	No					
		04671168	9	No		EX0			
		04671168	1	No					
3	RELAY, Mini								
		04671168	1	No					
		04671168	9	No		EX0			
		04671168	1	No					
4	FUSE CARTRIDGE, 30 Amp	04868007AA	1	Yes		EX0			
	FUSE	04868007AB	1	Yes					
5	FUSE CARTRIDGE, 50 Amp	06102078AA	1	No		EX0			
6	FUSE, Mini, 10 AMP, Red	000ATM10	5	No		EX0			
7	FUSE, Mini, 15 AMP, Light Blue	000ATM15	1	No		EX0			
8	FUSE, Mini, 20 AMP, Yellow	000ATM20	11	No		EX0			
9	FUSE, Mini, 25 Amp, Natural	000ATM25	1	No		EX0			
10	FUSE, Maxi, 50 AMP, Red	000MAX50	1	No		EX0			
11	FUSE, Mini, 30 AMP, Green	000ATM30	1	No		EX0			

Item	Description	Part Number	Qty	Supersedence	Tech Tip	Engine	Trans	Line	Body
12	FUSE, Maxi, 30 Amp, Green	000MAX30	1	No		EX0			
13	FUSE, Maxi, 40 AMP, Orange	000MAX40	1	No		EX0			
-14	COVER, Power Distribution Center	68026933AA	1	No		EX0			

Note: The item number that is listed in negative(-) indicates there is no illustration available.